



RAZER MONITOR STAND CHROMA

MASTER GUIDE


Measuring 19.7" long and 8.27" wide, this stand boosts your monitor or other devices to the perfect height. It conveniently features a built-in 4-port USB-C hub and a sleek slot for all your gear. Customize your RGB lighting with Razer Chroma and take your battlestation to the next level.

CONTENTS

1. WHAT'S INSIDE	3
2. WHAT'S NEEDED	4
3. LET'S GET YOU COVERED.....	4
4. GETTING STARTED.....	5
5. CUSTOMIZING YOUR MONITOR STAND.....	6
6. CONFIGURING YOUR RAZER MONITOR STAND CHROMA VIA RAZER SYNAPSE.....	7
7. SAFETY AND MAINTENANCE	21
8. LEGALESE	22


1. WHAT'S INSIDE

- Razer Monitor Stand Chroma



- A. Chroma RGB button*
- B. USB 3.2 Gen 1 Type A ports
- C. USB 3.2 Gen 1 Type C port (downstream)
- D. Underglow lighting powered by Razer Chroma RGB
- E. Anti-slip rubber feet
- F. USB 3.2 Gen 1 Type C port (upstream)**
- G. HDMI 2.0 port†

- USB Type C to Type C cable



- Important Product Information Guide

* Remappable via Razer Synapse.

**For complete functionality, connect to a USB Type C host that supports 15W. Limited functionality may occur when connected to a 7.5W USB Type C host.

†Supports single display up to 3840 x 2160p @ 60Hz. Available resolution may vary depending on your system's specifications.

2. WHAT'S NEEDED

PRODUCT REQUIREMENTS

- USB Type C port*

RAZER SYNAPSE REQUIREMENTS

- Windows® 10 64-bit (or higher)
- Internet connection for software installation

**For complete functionality, connect to a USB Type C host that supports 15W. Limited functionality may occur when connected to a 7.5W USB Type C host.*


i *The monitor stand can support devices weighing up to 20 kg (44 lbs).*

3. LET'S GET YOU COVERED



Register your product and score exclusive benefits


razerid.razer.com/warranty



*Your product's serial number
can be found here.*

4. GETTING STARTED


1. Place your monitor on the stand and connect its HDMI port to the stand's HDMI 2.0 port using an HDMI cable*.



**not included.*

i The monitor stand can support devices weighing up to 20 kg (44 lbs). To ensure stability and device safety, use caution when placing devices on the stand and avoid overloading it.



2. Connect the stand's USB Type C port (upstream) to the USB Type C port of your computer using the USB Type C to Type C cable.




i Install Razer Synapse when prompted, or download the installer from razer.com/synapse

5. CUSTOMIZING YOUR MONITOR STAND

ENABLING / DISABLING LIGHTING



CYCLING BETWEEN CHROMA EFFECTS



STATIC > BREATHING > SPECTRUM CYCLING > WAVE > FIRE > STARLIGHT


***Repeat until desired effect is active.*

RAZER SYNAPSE APP

Remap the monitor stand's RGB button, personalize its lighting with a variety of striking effects, and sync it with all your Razer Chroma devices for an immersive setup that complements your workstation's aesthetic.

i *Only available on Windows 10 64-bit or higher. Laptop USB connectivity is required to customize the monitor stand via Razer Synapse.*

6. CONFIGURING YOUR RAZER MONITOR STAND CHROMA VIA RAZER SYNAPSE

 *Disclaimer: This guide provides an overview of the New Razer Synapse app and may only partially cover some of the features of your device. The New Razer Synapse requires an Internet connection to install, update, access, and save cloud-based features. Registering for a Razer ID account is recommended but optional. All features listed here are subject to change based on the current version, connected device(s), and supported add-ons.*

SYNAPSE TAB

The Synapse tab is your default tab when you first launch Razer Synapse. Use the following buttons below to navigate the user interface:

— Minimize

Clicking this button will minimize the app to the taskbar while it runs in the background.

 Maximize

This button expands the browser window to fill the entire screen. To restore the window to its original size, click the maximize button again.

✕ Close

This button will close all relevant tabs and terminate the application completely.

< Previous Tab

Clicking this button will return you to the last tab you have visited.

< Next Tab

Clicking this button will move you to the next page if you've recently used the Previous Tab button.

Refresh Tab

This button reloads the current page. Use this if a page isn't displaying correctly or you want to see the latest content.

Download Update

If this button appears, that means there are changes to the app. Use this if a page isn't displaying correctly or you want to see the latest content.

More

Clicking this button will open a pop-up so you can easily access your Devices, Modules, and Other Installed Apps tabs.

Settings

Clicking this button will open the Settings tab, so you can quickly change the settings to this app.

Profile


This button will open a pop-up to access the Log In, Feedback, Rate This Software, Add WiFi Device, and Exit options.

Info

Hovering over this button will pop up an additional information about a feature or function.


Dashboard

The Dashboard subtab is an overview of your Razer Synapse, where you can access all your Razer devices, modules, and online services.



Gamer Room

The Gamer Room subtab shows all devices with the Razer Aether Light feature. From here, you can view and manage your Gamer Room-supported devices.



Synapse Override


This section allows you to select and customize your device's lighting and make it react to Chroma-enabled games and Chroma Connect apps using Razer Synapse.

Controlled By Gamer Room App

This section displays all supported devices controlled remotely by the Gamer Room app.

Devices & Modules


The Modules subtab displays all installed and available modules for installation.



Global Shortcuts

Bind operations or Razer Synapse functions to custom key-combinations from any Razer Synapse-enabled device inputs, which apply across all device profiles.

 *Only Razer Synapse-enabled device inputs will be recognized.*



MONITOR STAND CHROMA

The MONITOR STAND CHROMA tab is the main tab for your Razer device. You can change your device settings from here, such as lighting and button assignment. Any changes under this tab will be saved automatically to your local system and cloud storage. Use the following buttons below to access your profile options:

 Profiles Dropdown Bar


Clicking this dropdown bar will display all the profiles for this device so you can quickly change profiles.

... Miscellaneous



Clicking this button will open a pop-up with options related to your current profile.

Customize


The Customize subtab is for modifying your Razer device's button mapping and light settings.




Profile


Profile is a data storage system that keeps all your Razer device's settings. By default, the profile name is based on your system's name. Clicking the dropdown bar () will display all profiles for this device so you can quickly switch between them. To add, import, rename, duplicate, export, or delete a profile, press the profile's corresponding Miscellaneous button ().

Remap Menu

Clicking the Remap Menu button () will reveal all current assignments for your Razer device and allow you to change their assignments.



Alternatively, you can skip a specific assignment by selecting it on the Customize tab.



Upon selecting an assignment, you may then change it to one of the following functions:

Default

This option enables you to return the button to its original setting.

Keyboard Function

This option changes the button assignment into a keyboard function. You can also choose to enable Turbo mode, which allows you to emulate repeatedly pressing the keyboard function while the button is held down.

Mouse Function

This option allows you to change any button into a mouse function. Listed below are the functions which you can choose from:

- Left Click - Performs a left mouse click using the assigned button.
- Right Click - Performs a right mouse click using the assigned button.
- Scroll Click - Activates the universal scrolling function.
- Double Click - Performs a double left click using the assigned button.
- Scroll Up - Performs a “Scroll Up” command using the assigned button.
- Scroll Down - Performs a “Scroll Down” command using the assigned button.
- Mouse Button 4 - Performs a “Backward” command for most internet browsers.
- Mouse Button 5 - Performs a “Forward” command for most internet browsers.
- Scroll Left - Performs a “Scroll Left” command using the assigned button.
- Scroll Right - Performs a “Scroll Right” command using the assigned button.
- Repeat Scroll Up - Continuously performs a “Scroll Up” command as long as the assigned button is pressed.
- Repeat Scroll Down - Continuously performs a “Scroll Down” command as long as the assigned button is pressed.
- Repeat Scroll Left - Continuously performs a “Scroll Left” command as long as the assigned button is pressed.
- Repeat Scroll Right - Continuously performs a “Scroll Right” command as long as the assigned button is pressed.

You can also choose to enable Turbo mode in some of the mouse functions, which allows you to emulate repeatedly pressing and releasing said function while the button is held down.

Macro

A Macro is a prerecorded sequence of keystrokes and button presses that is executed with precise timing. By setting the button function to Macro, you can conveniently execute a chain of commands. This function will only be visible when the Macro module is installed.

Inter-device

Inter-device allows you to change the functionality of other Razer Synapse-enabled devices. Some of these functionalities are device-specific such as using your Razer gaming keyboard to change the Sensitivity Stage of your Razer gaming mouse.

Switch Profile

Switch Profile enables you to quickly change profiles and load a new set of button assignments. An on-screen notification will appear whenever you switch profiles.

Switch Chroma Effect

Switch Chroma Effect allows you to easily switch between all Chroma Effect Profiles in Chroma Studio. This function will only be visible when the Chroma Studio module is installed.

Launch

Launch Program lets you open an app or a website using the assigned button. When you select Launch Program, two choices will appear, requiring you to search for a specific app you want to open or write the website address you want to visit.

Multimedia

This option allows you to assign multimedia controls to your Razer device. Listed below are the multimedia controls you can choose from:

- Volume Down - Decreases the audio output.
- Volume Up - Increases the audio output.
- Mute Volume - Mutes the audio.
- Mic Volume Up - Increases the microphone volume.
- Mic Volume Down - Decreases the microphone volume.

- Mute Mic - Mutes the microphone.
- Mute All - Mutes both microphone and audio output.
- Play / Pause - Play, pause, or resume current media playback.
- Previous Track - Play the previous media track.
- Next Track - Play the next media track.

↗ Windows Shortcuts

This option allows you to assign your preferred button into a Windows Operating System shortcut command. For more information, please visit: support.microsoft.com/kb/126449

☰ Text Function

Text Function enables you to type a prewritten text with a touch of a button. Simply write your desired text on the given field, and your text will be typed whenever the assigned button is pressed. This function has full Unicode support, and you can also insert special symbols from character maps.

⊘ Disable

This option renders the assigned button unusable. Use Disable if you do not want to use the selected button or if it interferes with your gaming.

Brightness


You can turn off your Razer device's lighting by toggling the Brightness option or increase/decrease the luminance using the slider.







Switch Off Lighting


This is a power saving tool which allows you to disable your device's lighting in response to your system's display turning off.

Quick Effects


A number of quick effects can be selected and applied to your device's lighting, as listed here:


	Name	Description	How to set up
	Ambient awareness	The lighting on the device will reflect the averaged color on the selected screen region	Select or customize a screen region

	Breathing	The lighting will fade in and out of the selected color(s)	Select up to 2 colors or randomize colors
	Fire	The LEDs will light up in warm colors to mimic the motion of flames.	No further customization required
	Spectrum cycling	The lighting will cycle between 16.8 million colors indefinitely	No further customization required
	Starlight	Each LED will have a chance of fading in and out at a random time and duration.	Select up to 2 colors or randomize colors and select a duration
	Static	The stand will remain lit in the selected color.	Select a color
	Wave	The lighting will scroll in the direction selected	Select a wave direction

If you have other supported Razer Chroma-enabled devices, you can synchronize their quick effects with your Razer device by clicking the Chroma Sync button ().


Advanced Effects

The Advanced Effects option allows you to choose a Chroma Effect Profile you want to use on your Razer Chroma-enabled peripheral. To start making your own Chroma Effect Profile, press the Launch Chroma Studio button ().

 *Some lighting effects listed here may not be available for your device. Only other Razer devices that support the selected lighting effect will synchronize.*

LINKED GAMES


The Linked Games tab allows you to add apps, view peripherals linked to apps, or search for listed apps. You can also sort apps based on alphabetical order, last played, or most played. Apps will still be listed here, even if not linked to a Razer device. To add an app that is not listed on the screen, you can use the Add button (+) to search for it manually or use the Scan button (📷) to search for it automatically. Click the Search button (🔍) to look for a specific game or program from the list.



To link an app to your Razer device, click on it from the list and select a device and its profile. This will automatically set your device to the selected profile whenever you launch the app.

SETTINGS

The Settings tab, accessible by clicking the Settings button (⚙️), enables you to configure numerous options as listed below:



Auto Launch

The Auto Launch option allows you to configure the startup behavior of the app.

Notifications

The Notifications option allows the app to display on-screen notifications even if you run full-screen apps.

Recommendations

Recommendations enable us to show the latest products and features on your Dashboard based on your installed devices and linked games.

Tutorials Reset

Selecting the Reset button will reactivate all tutorials that help you acquaint yourself with Razer Synapse's features.

Profile Migration

Move all your connected Razer Synapse 3 Profiles, Macros, and Chroma effects to the New Razer Synapse.

Device Lighting

This option lets you choose which app will control the lighting effects on your device.

Language


This option lets you change the display language of Razer Synapse.

About

The About section shows the current software version, displays the copyright statement, and provides relevant links for Razer's terms of use. You may also use this option to quickly access Razer's social communities.

FEEDBACK

Help us improve Razer Synapse by giving your comments, suggestions, and problems with the software. You can contact us directly using this tab and even earn rewards for reporting bugs.



The screenshot shows the Razer Synapse Feedback interface. At the top, there is a navigation bar with tabs for SYNAPSE, MONITOR STAND CHROME, LINKED GAMES, SETTINGS, and FEEDBACK. The FEEDBACK tab is active. The form contains the following fields:

- Select Type: A dropdown menu with "Razer Synapse" selected.
- Email (Optional): A text input field.
- Device Name: A dropdown menu.
- Subject: A text input field.
- Detail your feedback: A large text area for providing details.

At the bottom of the form, there is a green "SUBMIT" button and a character count "0 / 32000". Below the form, there is a small text link: "Earn rewards for reporting bugs! Join the Bug Bounty Program".

7. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer Monitor Stand Chroma, we suggest that you adopt the following guidelines:

Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device, and go to support.razer.com where you can find FAQs, guides, and contact information to our Razer Advocacy team.

Always place the monitor stand on a stable surface to prevent accidental falls and make sure that it's positioned securely to support your monitor and/or device(s).

The monitor stand can support devices weighing up to 20 kg (44 lbs). To ensure stability and device safety, use caution when placing devices on the stand and avoid overloading it.

Organize cables neatly to prevent tripping hazards and maintain a clutter-free workspace.

When disconnecting any device from the monitor stand, avoid tugging on its cable wire abruptly. Gently unplug your device from its connector.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

MAINTENANCE

The Razer Monitor Stand Chroma requires minimum maintenance to keep it in optimum condition. Once a month, we recommend that you unplug it from the computer, disconnect all connected devices, and clean it using a soft cloth to prevent dirt buildup. Don't use soap or harsh cleaning agents.

8. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, “For Gamers. By Gamers.” and “Razer Chroma” logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States and other countries. Actual product may differ from pictures. All other trademarks are the property of their respective owners.

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Monitor Stand Chroma (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.