



# FIRMWARE INSTALLATION INSTRUCTIONS

RAZER BASILISK X HYPERSPEED FIRMWARE UPDATER GUIDE

---

## DRIVER INSTALLATION INSTRUCTIONS

### APPLICABLE MODEL NUMBERS

- RZ01-03150

### DRIVER NAME AND VERSION

Razer Basilisk X HyperSpeed Updater v1.01.09

Download the firmware updater here: <http://rZR.to/jNjIX>

### RELEASE NOTES:

- Fixed an issue where the cursor jitters when the DPI is set to 6500 and above and enhance pointer precision is set to OFF.

---

## INSTALLATION PROCESS

1. Download the latest firmware update by downloading the link found above.
2. Close Razer Synapse and all other running applications before proceeding with the update.
3. Run the downloaded firmware (The installer will prompt you to close Synapse and all other applications, if you have already done so, left click "OK" to proceed)
4. Connect the device and click "Update".
5. Wait for the update to complete.
6. Once the firmware has been successfully applied, left-click "Close" to exit the installer.