



FIRMWARE INSTALLATION INSTRUCTIONS

RAZER BASILISK V2 FIRMWARE UPDATER GUIDE

DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

- RZ01-03160

DRIVER NAME AND VERSION

Razer Basilisk V2 Updater v1.03.00_r1

Download the firmware updater here: <http://rZR.to/8r187>

RELEASE NOTES:



- Fixed an issue where the device sometimes stops working after a restart or waking up from sleep.
- Fix the issue where the device will not function when performing PM operation if connected through a USB 3.0 Hub.

PREPARATIONS

1. Make your laptop is plugged into a wall outlet and not just running on battery before proceeding.
2. Save any open documents on your computer and close all other programs before attempting the update.
3. Download the firmware from the link above. **Note:** It is recommended to download and install the latest firmware version.
4. Run updater the follow the installation steps below:

INSTALLATION PROCESS

1. Run the updater as shown below:

| | | | | | |
|---|---|---------------------------------------|-------------------|-------------|-----------|
|  | BasiliskV2_Mouse_FirmwareUpdater_v... | 1/16/2020 6:09 PM | Application | 29,744 KB | |
| <input checked="" type="checkbox"/> |  | BasiliskV2_Mouse_FirmwareUpdater_v... | 1/16/2020 6:07 PM | Application | 29,744 KB |


2. You may be prompted to confirm changes on your device by the User Account Control. Click "Yes" to confirm these changes.




3. Click "NEXT" to proceed. The installer will close all running Razer applications if you have not done so yet.



4. Connect the device to the computer and click "UPDATE".



5. Wait until the update process is complete. Do not interrupt.



6. When the update is complete, click "CLOSE".

