



FIRMWARE INSTALLATION INSTRUCTION

BLACKSHARK V2 PRO FIRMWARE UPDATER GUIDE

UPDATER INFORMATION

APPLICABLE MODEL NUMBERS

- RZ01-03420

UPDATER NAME AND VERSION

BlackShark V2 Pro_FirmwareUpdater_v1.00.11_r2

Download the firmware here: <http://rZR.to/1666b>

RELEASE NOTES:

- Microphone audio improvement.

PREPARATIONS


1. Make your laptop is plugged into a wall outlet and not just running on battery before proceeding.
2. Save any open documents on your computer and close all other programs before attempting the update.
3. Download the firmware from the link above.

Note: It is recommended to download and install the latest firmware version.

4. Once the file is ready, follow the installation steps below.

INSTALLATION PROCESS


1. Run the updater.

Name	Date modified	Type	Size
Application (19)			
 BlackShark V2 Pro_FirmwareUpdater_v1.00.11_r2	9/23/2020 2:59 PM	Application	12,649 KB


2. You may be prompted to confirm changes on your device by the User Account Control. Click "Yes" to confirm these changes.




3. Click "NEXT" to proceed. The installer will close all running Razer applications if you have not done so.



4. Connect the USB wireless dongle to the computer and click "UPDATE".



5. Wait until the update process is complete. Do not interrupt.



6. When the installation is complete, click "CLOSE".

