



DRIVER INSTALLATION INSTRUCTIONS

RAZER BLADE 15" (2018) BASE MODEL INTEL SOFTWARE GUARD
EXTENSIONS (SGX) PLATFORM SOFTWARE DRIVER VERSION
3.16.0.140

DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

- RZ09-02705

DRIVER NAME AND VERSION

Intel Software Guard Extensions (SGX) Platform Software Driver Version 3.16.0.140

INSTRUCTIONS

Note: This download is for the original driver that was installed on your Razer Blade Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.


- Ensure your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- Please save any open documents on your computer and close all other programs before attempting this update.
- Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to a location of your choosing (such as your desktop) to locate the files for the installation process.

<http://rZR.to/kRUmM>

- Once you have extracted the file proceed to the installation steps below.

INSTALLATION PROCESS

1. To initiate the installation of the Intel Software Guard Extensions software driver, click on the InstallPackage.bat (Windows Batch File) as shown in the image below. A Windows Terminal Shell window will appear briefly and then disappear. No further action is required.



Name	Date modified	Type	Size
PSW_INTEL_RS4	2/27/2019 2:48 PM	File folder	
InstallPackage	2/27/2019 10:48 PM	Windows Batch File	1 KB
Intel SGX Installation Guide for Windows	2/27/2019 10:48 PM	PDF File	280 KB
Intel SGX PSW Release Notes for Window...	2/27/2019 10:48 PM	PDF File	432 KB

2. End