



RAZER HUNTSMAN ELITE FIRMWARE UPDATE

VERSION 1.2.1.0

RAZER HUNTSMAN ELITE - CUSTOMER FIRMWARE UPDATER (V1.2.1.0)

HOW TO UPDATE TO THE RAZER HUNTSMAN ELITE V1.2.1.0

This document is a step by step process on how to update the Razer Huntsman Elite to firmware version 1.2.1.0

Release Notes:


- Fixes an issue where key/s are missing, unresponsive, or stuck when wrist rest is not properly attached.

Please see the Step by Step instructions for installing the update below.


1. Download the firmware update by clicking the following link:

http://dl.razerzone.com/drivers//Huntsman%20Elite//win//Huntsman%20Elite_KB_FirmwareUpdater_v1.02.01_r1.exe


2. Close Razer Synapse and all other running applications before proceeding with the update.
3. Run the downloaded firmware. The installer will prompt you to close Synapse and all other applications, once you have done that left click "OK" to proceed.




4. Connect the Huntsman Elite and click Update.



5. Wait for the update to complete.



6. Once the firmware has been successfully applied, left-click "Close" to exit the installer.



7. End