



# FIRMWARE UPDATER INSTRUCTIONS

RAZER VIPER ULTIMATE FIRMWARE UPDATER VERSION 1.02

---

## DRIVER INSTALLATION INSTRUCTIONS

### APPLICABLE MODEL NUMBERS

- RZ01-03050

### DRIVER NAME AND VERSION

Firmware Updater V1.02.00

### INSTRUCTIONS

Please follow the instructions below to download and install the updater for your Viper Ultimate. Following the installation, it is recommended to search for any available Windows Updates.


1. For laptop users: Ensure that your laptop is plugged into a wall outlet and not running on battery alone before proceeding.
2. Save any open documents on your computer and close all other programs before attempting this update.
3. Download the firmware updater from the link below.

<http://rZR.to/URYLI>

---

## INSTALLATION PROCESS


1. To initiate the initial process, run "ViperUltimate\_Mouse\_FirmwareUpdater\_v1.02.00" (Application) as shown in the image below:




2. Upon clicking the updater, you may be prompted to confirm changes to be used for your system by the User Account Control. Click "Yes" to confirm these changes.




3. Click on "Next" to proceed with the installation. **Note:** this will close all Razer applications.




4. Plug the USB wireless dongle into your PC and click on "Update".




5. A progress bar will appear indicating the status and progression of the installation process. Do not interrupt the installation process.




6. After the update is successful, click on "Next".



7. Connect the Viper Ultimate to your PC with the supplied USB cable and then click on "Update".



8. A progress bar will appear indicating the status and progression of the installation process. Do not interrupt the installation process.



9. Upon completion of the installation, click on "Close".

