



FIRMWARE INSTALLATION INSTRUCTIONS

RAZER HUNTSMAN MINI FIRMWARE UPDATER GUIDE

UPDATER INFORMATION

APPLICABLE MODEL NUMBERS

- RZ03-03390

DRIVER NAME AND VERSION

Razer Huntsman Mini Updater v1.01.00_r1

Download Link: <http://rZR.to/BzKQq>

RELEASE NOTES:

- Fixed an issue where the device sometimes stops working after a restart or waking up from sleep.


PREPARATIONS

1. Make sure your system is plugged into a wall outlet and not just running on battery before proceeding.
2. Save any open documents on your computer and close all other programs before attempting the update.
3. Download the firmware from the link above.
Note: It is recommended to download and install the latest firmware version.
4. Once the file is ready, follow the installation steps below.


INSTALLATION PROCESS

1. Run the updater.


Name




2. You may be prompted to confirm changes on your device by the User Account Control. Click "Yes" to confirm these changes.




3. Click "NEXT" to proceed. The installer will close all running Razer applications if you have not done so.



4. Connect the device to the computer and then click "UPDATE".



5. Wait until the update process is complete. Do not interrupt.



6. When the update is complete, click "CLOSE".

