



RAZER MOUSE GRIP TAPE

MASTER GUIDE

CONTENTS

1. WHAT'S INSIDE	2
2. WHAT'S NEEDED	2
3. INSTALLING THE GRIP TAPE	2
4. SAFETY AND MAINTENANCE	4
5. LEGALESE	5

1. WHAT'S INSIDE

- Razer Mouse Grip Tape*

**Grip tape sizes and pre-cut pieces will vary depending on the Razer mouse model.*

2. WHAT'S NEEDED

- Compatible Razer mouse*


**For an updated list of compatible Razer mice, visit support.razer.com*

3. INSTALLING THE GRIP TAPE


1. Thoroughly clean the mouse's surfaces where the grip tapes will be applied.
2. Remove a pre-cut piece from the grip tape set.
3. Align the pre-cut piece and affix it to the appropriate device surface.

i *You may make quick adjustments when applying the grip tape for the first time to ensure correct positioning. However, the grip tape will gradually lose its stickiness if removed and replaced multiple times.*


For Razer Basilisk V3 Pro, Razer Basilisk Ultimate, Razer Basilisk V3, Razer Basilisk V2, and Razer Basilisk X HyperSpeed




For all Razer DeathAdder variants (except Razer DeathAdder V2 Mini)




For Razer DeathAdder V2 Mini



For Razer Viper Mini



For all Razer Viper variants (except Razer Viper Mini)



4. Repeat steps 2 and 3 until all the pre-cut pieces are applied.

4. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer accessory, we suggest that you adopt the following guidelines:

- Should you have trouble operating the accessory properly and troubleshooting does not work, detach the accessory and contact the Razer hotline or go to support.razer.com for support.
- The accessory is intended for use only with compatible Razer devices, as listed on support.razer.com.
- Don't use or place the accessory near water, moisture, or other wet surfaces.
- Don't use or place the accessory near any heat, naked flame, or other hot surfaces such as radiators, stoves, fireplaces, and candles.

5. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, “For Gamers. By Gamers.”, and “Razer Chroma” logo are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Mouse Grip Tape (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.