



RAZER GOLIATHUS CHROMA 3XL

MASTER GUIDE


Powered by Razer Chroma™ RGB, our best-selling soft gaming mouse mat now comes in 3XL—ready to illuminate every victory in a stunning spectrum of colors. Light up your game in vivid brilliance as you swipe across the **Razer Goliathus Chroma 3XL** with blazing speed and precision.

CONTENTS

1. WHAT'S INSIDE	3
2. WHAT'S NEEDED	3
3. LET'S GET YOU COVERED	4
4. TECHNICAL SPECIFICATIONS	5
5. SETTING UP YOUR RAZER GOLIATHUS CHROMA 3XL	5
6. CONFIGURING YOUR RAZER GOLIATHUS CHROMA 3XL VIA RAZER SYNAPSE	6
7. SAFETY AND MAINTENANCE	15
8. LEGALESE	16

1. WHAT'S INSIDE

- Razer Goliathus Chroma 3XL



- A. Type A cable connector
- B. Mouse mat lighting Powered by Razer Chroma™ RGB
- C. Micro-textured cloth surface
- D. Non-slip rubber base

- Important product information guide

2. WHAT'S NEEDED

PRODUCT REQUIREMENTS

- Type A port

RAZER SYNAPSE REQUIREMENTS


- Windows® 10 64-bit (or higher)
- Internet connection for software installation

3. LET'S GET YOU COVERED



Register your product and score exclusive benefits

razerid.razer.com/warranty




Your product's serial number can be found here.

4. TECHNICAL SPECIFICATIONS

- Micro-textured surface balanced for speed and control
- Powered by Razer Chroma™ lighting with 16.8 million customizable color options
- Razer Synapse 3 enabled
- Non-slip rubber base
- Approximate size: 1200 mm / 47.24 in (Length) x 550 mm / 21.65 in (Width) x 4 mm / 0.15 in (Height)
- Thickness: 3.5mm
- Cable length: 2.1 m / 6.89 ft

5. SETTING UP YOUR RAZER GOLIATHUS CHROMA 3XL

Connect your Razer mouse mat to any of the USB ports on your PC.



i Install Razer Synapse when prompted or download the installer from razer.com/synapse

6. CONFIGURING YOUR RAZER GOLIATHUS CHROMA 3XL VIA RAZER SYNAPSE


i Internet connection is required for installation, updates, and cloud-based features. Registering for a Razer ID account is recommended but optional. All listed features are subject to change based on the current software version, the connected device(s), and supported apps and software.

SYNAPSE TAB

The Synapse tab is your default tab when you first launch Razer Synapse. This tab allows you to navigate the Dashboard subtab.


Dashboard

The Dashboard subtab is an overview of your Razer Synapse, where you can access all your Razer devices, modules, and online services.



Modules


The Modules subtab displays all installed and available modules for installation.



Global Shortcuts

Bind operations or Razer Synapse functions to custom key-combinations from any Razer Synapse-enabled device inputs, which apply across all device profiles. [Learn more about Profiles](#)

 *Only Razer Synapse-enabled device inputs will be recognized.*




MOUSE MAT TAB

The Mouse Mat tab is the main tab for your Razer Goliathus Chroma 3XL. From here, you can change your mouse mat's settings, such as profiles and lighting. Changes made under this tab are automatically saved to your system and cloud storage.

Lighting

The Lighting subtab enables you to modify your Razer device's light settings.



Profile






Profile is a data storage for keeping all your Razer peripheral's settings. By default, the profile name is based on your system's name. To add, rename, duplicate, or delete a profile, simply press the Miscellaneous button (●●●).


Brightness

You can turn off your Razer device's lighting by toggling the Brightness option or increase/decrease its luminance using the slider.

Quick Effects


A number of quick effects can be selected and applied to your mouse mat's lighting, as listed here:

	Name	Description	How to set up
	Audio meter	The mouse mat will light up according to the audio level with a default spectrum of colors	Select a Color Boost level
	Breathing	The lighting will fade in and out of the selected color(s)	Select up to 2 colors or randomize colors
	Reactive	The mouse mat will light up when you use a compatible Razer mouse's scroll wheel or click any of its buttons	Select a color and a duration
	Spectrum cycling	The lighting will cycle between 16.8 million colors indefinitely	No further customization required
	Static	The mouse mat will remain lit in the selected color	Select a color

If you have other supported Razer Chroma-enabled devices, you can synchronize their quick effects with your Razer device by clicking the Chroma Sync button ().

 *Only devices that support the selected lighting effect will synchronize.*

Advanced Effects

The Advanced Effects option allows you to choose a Chroma Effect you want to use on your Razer Chroma-enabled peripheral. To start making your own Chroma Effect, simply press the Chroma Studio button ().

Switch Off Lighting


Enable this power saving option to disable your device's lighting in response to your system's display turning off.




PROFILES TAB

The Profiles tab is a convenient way to manage all your profiles and link them to your games and applications.

Devices


View which games are linked to each device's profiles or which Chroma Effect is linked to specific games using the Devices subtab.



You can import Profiles from your computer or the cloud through the import button () or create new profiles within the selected device using the add button (). To rename, duplicate, export, or delete a profile, simply press the Miscellaneous button (). Each profile can be set to activate when you run an application using the Linked Games option.

Linked Games


The Linked Games subtab allows you to add games, view devices linked to games, or search for added games. You can also sort games based on alphabetical order, last played, or most played. Added games will still be listed here, even if they are not linked to a Razer device.



To link games to connected Razer devices or Chroma Effects, simply click on any game from the list, and then click **Select a device and its profile to launch automatically during gameplay** to select the Razer device or Chroma Effect it will link with. Once connected, you may click the Miscellaneous button (●●●) of the corresponding Chroma Effect or device to select a specific Chroma Effect or profile.

SETTINGS WINDOW

The Settings window, accessible by clicking the (⚙) button on Razer Synapse, enables you to configure the startup behavior and display language of Razer Synapse, view the master guides of each connected Razer device or perform a factory reset on any connected Razer device.



General tab

The General tab lets you change the software's display language, startup behavior, theme, and on-screen notifications display. You may also manually sync your profiles to the cloud (↻) or view the master guide of all connected Razer devices and installed modules.

Dashboard tab

Use the Dashboard tab to customize which Razer device recommendations based on your setup, and the games you play will appear on the Dashboard.

Reset tab

The Reset tab allows you to perform a factory reset on all connected Razer devices with on-board memory and/or reset Razer Synapse tutorials to acquaint yourself again with Razer Synapse's new features on its next launch.



All profiles stored on the selected device's on-board memory will be erased when you reset a Razer device.

About tab

The About tab displays brief software information and copyright statement, and provides relevant links for its terms of use. You may also use this tab to check for software updates, or as quick access to Razer's social communities.

7. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer Goliathus Chroma 3XL, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.

Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.

Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug the device to let the temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer Goliathus Chroma 3XL requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you unplug the device from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Don't use soap or harsh cleaning agents.

CAUTION: DO NOT FOLD, COMPRESS, OR OVERSTRETCH the mouse mat, as doing so may damage or deform the product and void the warranty. Allow the mouse mat to SETTLE ON A FLAT SURFACE to remove any creases.

8. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2022 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, “For Gamers. By Gamers.”, and “Razer Chroma” logo are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent, or other intellectual property right. The Razer Goliathus Chroma 3XL (the “Product”) may differ from pictures, whether on packaging or otherwise. Razer assumes no responsibility for such differences or any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.