



RAZER STREAM CONTROLLER X

MASTER GUIDE


With the **Razer Stream Controller X**, creativity comes easily↔. Manage your streaming and content creation seamlessly through one convenient device that controls all your apps and tools. Streamline your workflow so you can focus on what matters most↔—engaging the fans and growing your following.

CONTENTS

1. WHAT'S INSIDE	3
2. WHAT'S NEEDED	4
3. TECHNICAL SPECIFICATIONS.....	4
4. LET'S GET YOU COVERED	5
5. GETTING STARTED	6
6. CONFIGURING THE RAZER STREAM CONTROLLER X VIA RAZER SYNAPSE.....	8
7. SAFETY AND MAINTENANCE	12
8. LEGALESE.....	13

1. WHAT'S INSIDE

- Razer Stream Controller X



- A. Swappable Magnetic Faceplate
- B. 15 Switchblade buttons
- C. Detachable 50° Anti-Slip Magnetic Stand
- D. 2-meter USB-A to USB-C cable

- Important Product Information Guide

2. WHAT'S NEEDED

PRODUCT REQUIREMENTS

- Direct Type A connection to a PC

LOUPEDECK SOFTWARE REQUIREMENTS

- macOS® X 10.14 / Windows®10 64-bit (or higher)
- Internet connection for software installation


RAZER SYNAPSE REQUIREMENTS (OPTIONAL)

- Windows® 10 64-bit (or higher)
- Internet connection for software installation

3. TECHNICAL SPECIFICATIONS

- System requirements: macOS X 10.14 (and later), Windows 10 system (and later), Loupedeck software
- Size: 111 x 80.7 x 30mm
- Weight: 146g (Stream Controller X only), Angle Stand is 177g
- Interface: 15 Membrane Buttons
- Connectivity: 2 meter USB-A to USB-C cable
- Screen Angle: 8 degrees (Stream Controller X only), 50 degrees (Including stand)
- Inside the box/Package Contents: Razer Stream Controller X, 2 meter USB-A to USB-C cable, Detachable Stand

4. LET'S GET YOU COVERED




Your product's serial number can be found here.




Register your product and score exclusive benefits razerid.razer.com/warranty

5. GETTING STARTED

1. Connect the Razer Stream Controller X through the stand and to your computer.



2. Place the faceplate onto the Razer Stream Controller X, and then into the stand.



3. Download and install the latest Loupedeck Software from loupedeck.com/get-started.
i *The Loupedeck Software is required when using the controller and any of its features.*



4. Install Razer Synapse when prompted, or download the installer from razer.com/synapse to access additional features.



6. CONFIGURING THE RAZER STREAM CONTROLLER X VIA RAZER SYNAPSE


i *Internet connection is required for installation, updates, and cloud-based features. Registering for a Razer ID account is recommended but optional. All listed features are subject to change based on the current software version, the connected device(s), and supported apps and software.*

SYNAPSE TAB

The Synapse tab is your default tab when you first launch Razer Synapse. This tab allows you to navigate the Dashboard subtab.


Dashboard

The Dashboard subtab is an overview of your Razer Synapse, where you can access all your Razer devices, modules, and online services.



Modules


The Modules subtab displays all installed and available modules for installation.



Global Shortcuts


Bind operations or Razer Synapse functions to custom key-combinations from any Razer Synapse-enabled device inputs, which apply across all device profiles.

! *Only Razer Synapse-enabled device inputs will be recognized.*



STREAMING TAB

Use the Streaming tab to launch or download the Loupedeck Software and change the controller's application profile using Razer Synapse.



Profile

On the Razer Stream Controller X app, a profile is a pre-configured workspace designed to make the controller immediately usable and compatible with the supported application that you're using.


! *The Loupedeck Software is required for Razer Synapse to take control of the Razer Stream Controller X's profiles. It's also necessary that Dynamic Mode is turned OFF on the Loupedeck Software for the Razer Synapse app to have control over the controller's profiles.*

Quick Tips

- Visit [Loupedeck Software](#) for a detailed understanding of the Loupedeck Software and its features.
- Understand how each plugin works for application-specific profiles at [Loupedeck Plugin Guides](#).

SETTINGS WINDOW

The Settings window, accessible by clicking the (⚙️) button on Razer Synapse, enables you to configure the startup behavior and display language of Razer Synapse, view the master guides of each connected Razer device, or perform a factory reset on any connected Razer device.




General tab

The General tab lets you change the software's display language, startup behavior, theme, and on-screen notifications display. You may also manually sync your profiles to the cloud (↻) or view the master guide of all connected Razer devices and installed modules.

Reset tab

The Reset tab allows you to perform a factory reset on all connected Razer devices with on-board memory and/or reset Razer Synapse tutorials to acquaint yourself again with Razer Synapse's new features on its next launch.

 *All profiles stored on the selected device's on-board memory will be erased when you reset a Razer device.*

About tab

The About tab displays brief software information and copyright statement, and provides relevant links for its terms of use. You may also use this tab to check for software updates, or as quick access to Razer's social communities.

7. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using the Razer Stream Controller X, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for support.

Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.

Don't use or install the device near water, moisture, solvents, or other wet surfaces; expose it to high temperatures or direct sunlight for an extended period of time, or get moisture or liquid inside the device.

Maintain a minimum distance of at least 15 cm (6 in) between implanted medical devices and the device to reduce the risk of interference.

Keep the device and its components away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 15°C (59°F) to 35°C (95°F). Should the temperature exceed this range, unplug the device to let the temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer Stream Controller X requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

8. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, and “For Gamers. By Gamers.” are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States and other countries. Actual product may differ from pictures. All other trademarks are the property of their respective owners. Warranty not valid outside of product’s intended region.

©2022 LoupeDeck Ltd. All rights reserved.

macOS is a trademark of Apple Inc., registered in the U.S. and other countries and regions.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Stream Controller X (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.