



RAZER USB-C 130W GAN CHARGER

MASTER GUIDE


CONTENTS

1. WHAT'S INSIDE	2
2. WHAT'S NEEDED	3
3. LET'S GET YOU COVERED	3
4. SETTING UP YOUR RAZER USB-C 130W GAN CHARGER	4
5. SAFETY AND MAINTENANCE	6
6. LEGALESE.....	7

1. WHAT'S INSIDE


- Razer USB-C 130W GaN Charger

(Model No: RC21-0170)




- A. Power indicator
- B. USB Type-C
- C. USB Type-A ports

- Regional adapter plugs



- 100W USB Type-C cable



- Important Product Information Guide


2. WHAT'S NEEDED

PRODUCT REQUIREMENTS

- Laptop with a free USB Type-C port or other compatible devices
- AC power outlet

3. LET'S GET YOU COVERED

You've got a great device in your hands, complete with a 2-year limited warranty coverage. Now maximize its potential and score exclusive Razer benefits by registering at razerid.razer.com



Serial No.: 4621WWAAAAAXXXX


*Your product's serial number
can be found here.*

Got a question? Ask the Razer Support Team at support.razer.com


4. SETTING UP YOUR RAZER USB-C 130W GAN CHARGER

1. Use the appropriate plug for your region.


- US 2-Pin




- EU 3-Pin




- EU 2-Pin




- To Remove:




2. Connect your Razer device to a power outlet. The power indicator will light up to show that it is receiving adequate power.



3. Use the provided 100W USB Type-C cable to connect your laptop and/or other electronic devices to the USB ports.



 *The maximum shared power output for USB Type-C is up to 112W; and up to 18W for USB Type-A. The combined power output for all ports is up to 130W.*

5. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer USB-C 130W GaN Charger, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for support.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer USB-C 130W GaN Charger requires minimum maintenance to keep it in optimum condition. Once a month we recommend you unplug the device from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

6. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, and “For Gamers. By Gamers.”, are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer USB-C 130W GaN Charger (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.