

## How to customize the HyperScroll Pro Wheel of the Razer Naga V2 Pro

<https://youtu.be/BEdluc87ptQ>

This video will show you how to customize the HyperScroll Pro Wheel of your Razer Naga V2 Pro.

The Razer Naga V2 Pro is geared with unlimited configurations and scroll feel with its adjustable tactility, resistance, and steps. This allows for firmer and more distinct scrolls for precise weapon switching, or for softer and smoother scrolls with multiple steps to easily spam inputs.

Let's get started.

Toggle between the five presets and one custom mode on Razer Synapse 3 for faster and easier customization.

Go to Razer Synapse 3 and choose the Razer Naga V2 Pro on the dashboard

Next, go to Scrolling tab to reorder or disable the scroll wheel stages in Gaming Mode.

Choose between the standard, distinct, ultra-fine, adaptive, or free scroll presets.

Take advantage of its unlimited configuration by

going to Active Scroll Wheel Haptics and

click Customize.

Adjust the Scroll Tension from a scale of zero to a hundred. This changes the strength required for each tick of the scroll wheel. The lower the number, the easier it is to scroll—with “zero” providing a completely smooth scroll feel.

Adjust the number of steps required for a complete revolution of the scroll wheel from 8 to 96. Lower steps mean thicker, chunkier ticks. Higher steps provide finer ticks and more inputs.

You can also create your very own custom scroll wheel haptics by dragging the points and curves in the Scroll Up or Scroll Down graphs.

There you have it. You have fully customized the HyperScroll Pro Wheel of your Razer Naga V2 **Pro**.