

How to dry off the Razer Hammerhead Pro HyperSpeed earbuds

This video is a step-by-step process on how to dry off the Razer Hammerhead Pro HyperSpeed earbuds.

The following are the common issues you will encounter when earbuds get wet:

No sound from earbuds

Malfunctioning microphone

Earbuds not charging

Bad connections with other devices

Let's get started.

First, use a soft dry cloth to wipe off any water that gets on the earbuds.

Next, remove the earbud tips and position the earbuds downward then shake several times to get the water out.

Position the air holes found on top of the earbuds downward and gently tap them about five to 10 times to remove any water collected inside.

Finally, leave the earbuds to dry at room temperature after completing the previous steps.

Here are some tips to prevent the earbuds from liquid damages:

Avoid using earbuds in the rain.

Avoid using the earbuds with wet hands.

Take the earbuds out of the pocket before laundry to prevent them from submerging in water.

That's it! Earbuds should now be dry and safe to use.