

## How to install or upgrade Razer Chroma App

This video is a step-by-step process on how to install or upgrade Razer Chroma App

To install Razer Chroma App, you need the following:

Windows 10 or 11 64-bit Operating System

Valid e-mail, software download, license acceptance, and an internet connection to activate full features and software updates.

Before we proceed, be aware that installing the applications will uninstall Razer Synapse 3.

Let's get started.

Go to the Razer Synapse installer download page by clicking the link in the description, then click "Download Now".

Once the download is complete, run the installer.

Click "Yes" if the User Account Control window pops up to proceed.

Check "RAZER CHROMA" then click "INSTALL".

Installation may take a few minutes to complete.

Once the installation is complete, ensure the "Launch RAZER CHROMA" is checked, then click "GET STARTED!"

Log in with your Razer ID to take full advantage of the Razer Chroma features.

That's it! You have successfully installed the Razer Chroma App.