

How to remove and install stabilizers on the Razer BlackWidow V4 75%

This video is a step-by-step process on how to remove and install stabilizers on the Razer BlackWidow V4 75%.

Let's get started.

First, unplug the keyboard from your PC.

Then, remove the keycaps from the keyboard. For a guide on how to replace keycaps on a Razer keyboard, see the link in the description.

Afterwards, gently pull out the switches using a switch puller.

You can now proceed to removing the stabilizer. Using a thin tool, unclip the stabilizers. To do this, push the small tabs on the stabilizers and use your fingers to pull them up, away from the keyboard.

You have now successfully removed the stabilizers.

If you want to install the stabilizer back, start by grabbing the stabilizer and putting its bar underneath your keyboard's plate. Once it's in the right position, snap the stabilizer's plastic housing back in place.

You can then reattach your keyboard's switches and keycaps. Make sure to firmly push them into place.

Plug the keyboard into your PC and perform a test.

That's it! You have successfully removed and installed stabilizers on your Razer BlackWidow V4 75%.