

This video is a step-by-step process on how to customize the Razer Key Light Chroma.

Before we proceed,

you need to download and install the latest version of Razer Synapse for PC or the Razer Streaming app for your mobile device. Ensure that Razer Synapse is up-to-date.

Let's get started.

Switch on the Razer Key Light Chroma.

Press and hold the reset button for three seconds to activate pairing mode.

The Razer Key Light Chroma will flash in blue to indicate that the pairing mode is active.

Using your PC:

Open Razer Synapse 4.

Click on "ADD WIFI DEVICE" from the Razer Synapse dashboard

Click on the Razer Key Light Chroma once it appears

Select the WiFi network that you want to connect to and enter the password.

Ensure that you are connecting to a 2.4Ghz network.

Once done, you can either add another device

or go straight into customizing the lighting on your Razer Key Light.

When using the Razer Streaming app on your mobile device:

Launch the app and follow the onscreen instructions.

The Razer Key Light Chroma will light up in solid white to indicate that it is now connected to your network.

Tap on “Razer Key Light”.

To adjust the brightness or warmth:

Ensure “Brightness” is toggled on.

Tap on the property to adjust then drag the slider to your preferred level.

To add or customize a Chroma effect:

Ensure “Chroma Effect” is toggled on.

Tap on “Chroma Effect”.

Select your preferred effect and color then adjust its properties to your liking.

When customizing the Razer Key Light Chroma,

make sure your PC or mobile device is in the same Wi-Fi network.

Also, if your router is with Delivery Traffic Indication Message or DTIM,

you need to change the default DTIM value which is three to one.

This is to ensure timely message delivery to connected devices.

Refer to your router’s manual for a guide in changing DTIM values.

There you have it,

you have successfully customized your Razer Key Light Chroma.