

This video is a step-by-step process on how to pair your Gamer Room devices to the Razer Gamer Room App and Razer Synapse 4

To pair your Gamer Room devices to the App and Razer Synapse 4, ensure the following:

You installed Razer Gamer Room App from Appstore or Google Playstore

Your WiFi supports 2.4Ghz bandwidth

Your PC and Mobile Phone are connected to the same 2.4Ghz WiFi network and have Bluetooth enabled

Let's get started.

Plug in your Gamer room device and set it to pairing mode.

*Note:

For more information on how to set your Gamer Room device to pairing mode, refer to the manual guide.

Open the Razer Gamer Room App from your mobile device and tap on the menu icon.

Tap on "Add Devices".

From here on, you can choose either to "Scan a Matter QR code" or tap on your device to pair it directly without scanning the Matter QR code.

Once you've done pairing, your Gamer Room device will appear on the dashboard of the Gamer Room App.

To assign your Gamer room devices, simply tap on "Rooms" and tap on "Add Rooms".

From here on, you can either use the preset name or create your own. Once done, tap on "Create".

You can then add devices that you have paired with the app to your "Rooms".

Once done, you will be able to see it on your Razer Gamer Room App dashboard.

Now onto Razer Synapse 4

Launch Razer Synapse 4 on your PC and click on "GAMER ROOM" at the top menu.

Once you're in the GAMER ROOM tab, click on "Add a new device".

Click "Search" on the pop-up window and choose your Gamer room device once it appears.

After pairing, you can either "Add Another Device" or start customizing the lighting for your Gamer Room device.

From here on, you'll be able to control your Gamer Room device via Razer Synapse 4.

If you want to control it via the Gamer Room App, simply click on the device and turn off "SYNAPSE OVERRIDE" or go to your Gamer Room App and tap on "TAKE CONTROL".

That's it! You have successfully paired your Gamer Room devices to the Razer Gamer Room App and Razer Synapse 4.